

<b>Produkt:</b>	<b>LL STAGE WASH 600 RGBAW [16b]</b>	
Soft ID1:	W 1v1	Hw: 296
Soft ID2:	1v3	Hw: 315

## DMX channels:

### Mode1 8b-15 ch (+2ch): Dip1=Off, Dip2=Off

Ch 1 = Red 1	Ch 6 = Red 2	Ch 11 = Red 3	Ch 16 = Master ( if Dip3 = On )
Ch 2 = Green 1	Ch 7 = Green 2	Ch 12 = Green 3	Ch 17 = Strobo ( if Dip3 = On )
Ch 3 = Blue 1	Ch 8 = Blue 2	Ch 13 = Blue 3	
Ch 4 = Amber 1	Ch 9 = Amber 2	Ch 14 = Amber 3	
Ch 5 = White 1	Ch 10 = White 2	Ch 15 = White 3	

### Mode2 8b-5 ch (+2ch): Dip1=On, Dip2=Off

Ch 1 = All Red	Ch 6 = Master ( if Dip3 = On )
Ch 2 = All Green	Ch 7 = Strobo ( if Dip3 = On )
Ch 3 = All Blue	
Ch 4 = All Amber	
Ch 5 = All White	

### Mode3 16b-30 ch (+3ch): Dip1=Off, Dip2=On

Ch 1 = Red 1 H (High)	Ch 11 = Red 2 H	Ch 21 = Red 3 H	Ch 31 = Master H ( if Dip3 = On )
Ch 2 = Red 1 L (Low)	Ch 12 = Red 2 L	Ch 22 = Red 3 L	Ch 32 = Master L ( if Dip3 = On )
Ch 3 = Green 1 H	Ch 13 = Green 2 H	Ch 23 = Green 3 H	Ch 33 = Strobo ( if Dip3 = On )
Ch 4 = Green 1 L	Ch 14 = Green 2 L	Ch 24 = Green 3 L	
Ch 5 = Blue 1 H	Ch 15 = Blue 2 H	Ch 25 = Blue 3 H	
Ch 6 = Blue 1 L	Ch 16 = Blue 2 L	Ch 26 = Blue 3 L	
Ch 7 = Amber 1 H	Ch 17 = Amber 2 H	Ch 27 = Amber 3 H	
Ch 8 = Amber 1 L	Ch 18 = Amber 2 L	Ch 28 = Amber 3 L	
Ch 9 = White 1 H	Ch 19 = White 2 H	Ch 29 = White 3 H	
Ch 10 = White 1 L	Ch 20 = White 2 L	Ch 30 = White 3 L	

### Mode4 16b-10 ch (+3ch): Dip1=On, Dip2=On

Ch 1 = All Red H (High)	Ch 11 = Master H ( if Dip3 = On )
Ch 2 = All Red L (Low)	Ch 12 = Master L ( if Dip3 = On )
Ch 3 = All Green H	Ch 13 = Strobo ( if Dip3 = On )
Ch 4 = All Green L	
Ch 5 = All Blue H	
Ch 6 = All Blue L	
Ch 7 = All Amber H	
Ch 8 = All Amber L	
Ch 9 = All White H	
Ch 10 = All White L	

## Extention and control functions:

DipBCD = 000	= DMX address 001
DipBCD = 001 – 512	= DMX address 001 – 512
DipBCD = 9xx	= AutoRun1 ( 12s/10s 5steps R, G, B, A, W )
DipBCD = 8xx	= AutoRun2 ( 8s/2s 10steps R, RG, G, GB, B, BA, A, AW, W, WR )
DipBCD = 7xx	= AutoRun3 ( 1s/0s 17steps R, G, B, A, W, R, G, B, A, W, RG, GB, BR, RG, GB, BR, AW )
DipBCD = 6xx	= AutoRun4 ( 1s/0s 4steps RA, W, GB, W )

Dip3 = On	= add channels: Master, Strobo
Dip4 = Off	= Standard curve for Mode 8b
Dip4 = On	= UltraSoft curve for Mode 8b